

## PROCEDURE FOR INSTALLING GENERATOR SET ON ROOF TOP (RES)

## **NOTICE**

All the members are informed that in Residential Building a generator set may be installed as per following:

- 1. Generator set to be installed in basement or front lawn 5 ft. away from boundary walls within the premises.
- 2. Generator set must be installed with sound proof canopy and noise beyond the boundary limit shall not be more than 15 decibels.
- 3. Maximum capacity of generator set is 25 KVA.
- 4. Generator set will not be used as prime supply but only in failure of WAPDA / MEPCO power supply.



**Note:** This supersedes all previous rulings / notices on this subject.